

RUSH BOXER



- 1 ゲーム × 100 (研留) ● I 人用 1 47-A Y 200 (FESS)
- ●1人間かり人間のボタンを押して下さい。レバ ーでボクサーを上下左右に終動させ、パンチボ タンを押して相手を DOWN させて下さい。
- ●レバーを上げると無菌が早く動き、下げるとス テップバックした状態となり、タイムが早く減 質されます。
- ボクサーは右利き、右から攻撃すると有利です。 ●チャンピオンを DOWN させると、ボーナスプレ
- イI回分又は、ボーナス点が加算されます。 ●時間内に相手を全て DOWN させると、残り時間
- がルーレット方式により無大されます(1~40倍) ●手持ちグローブがきになると、ゲーム終了。

HOW TO PLAY

e 1 Player · · · · · 1 coin per game 2 Players ---- 2 coins per game Push a button either for 1 player or for 2 players.

Operate a lever to shift a boxer's position right and left, up and down, Shift the lever However to get one-up on the opponent

Down· · · to hold back (Timer runs out) e Push a button to land a short knockdown punch on the jaw. e The hover is right-handed Deliver the punch from the right-hand side. Bonus point will be added if the

opponent was licked. e Game will be over when you have run out of all the boxing-gloves.









W95-1800 o(高さ)600×(幅)860×(患行)560mm ○ 類: 72 kg

OR №: 100V AC±10V 50/60Hz OSTANOS SEW

W95-1800 O(H)1780×(W)630×(D)760mm O'Weight! Slice

O Power: 100 V AC+10 V 50/40 Hz O Power Consumption: 98W

BC-SEE MICH DUF 97 〒252 神奈川県県沢市亀井野2235-1